

Kurzanleitung / Quick user guide

Transponder TR30

- 1 Antenne (schwenkbar)
- 2 Akkuladezustand-Anzeige (orange) für optionalen Akku (nicht relevant bei Einzeleinsatz mit USB Verbindung)
- 3 Anzeige (rot) für Trägerkennung
- 4 Anzeige (grün) für Empfangsaktivität
- 5 Anzeige (gelb) für Sendeaktivität
- 6 Stativbefestigungsmutter
- 7 Sicherungsöse gem. BGV C1
- 8 Ein- / Ausschalter
- 9 Verbindung zum steuernden PC über RS232 oder RS 485 (XLR 5pol Buchse)
- 10 Verbindung zum steuernden PC über USB (XLR 6pol Stecker) oder Anschluss optionales Netzteil, falls Vervindung über RS232/485

Transponder / Controller TR30

- 1 Antenna (swivel-mounted)
- 2 LED (ora) for status of rechargeable battery as option (not relevant for single operation mode with USB connection)
- 3 LED (red) for carrier detection
- 4 LED (grn) for reception activity
- 5 LED (yel) for transmission activity
- 6 tripod mounting screw
- 7 Safety eye
- 8 On/Off key
- 9 Connection to Control PC via RS232 or RS485 (XLR female 5 pin)
- 10 Connection to Control PC via USB (XLR male 6 pin) or connection to optional power supply if using RS232/485

